


5,000 mAh Magnetic Wireless Power Bank

ReelSafe™ · RC-SS5K/PWB5021



User Manual

Thank you for choosing ReelCharge. Please read this manual before using your product to ensure safe and optimal performance. Keep this guide for future reference.

1. Product Specifications

Product: ReelSafe™ 20 W 5,000 mAh Qi-compatible Semi-Solid-State Power Bank

Model: RC-SS5K/PWB5021

Battery capacity: 5,000 mAh / 19.25 Wh

Battery type: Semi-solid-state battery

USB-C input: 5 V = 3 A, 9 V = 2 A (18 W max)

USB-C output: 5 V = 3 A, 9 V = 2.22 A (20 W max)

Wireless output (Qi): 5 W / 7.5 W / 10 W / 15 W max

Maximum total power: 20 W


2. What's in the Box

- ReelSafe™ 5,000 mAh Power Bank (RC-SS5K/PWB5021)
- USB-C to USB-C cable
- User Manual

3. Product Overview

- Qi-compatible wireless charging surface
- Semi-solid-state battery technology
- USB-C input/output port
- LED battery percentage display
- Display activation button
- Magnetic alignment for compatible devices
- Compact card-sized design

3. Product Overview



- 1. Qi-compatible wireless charging surface
- 2. LED battery percentage display
- 3. USB-C input/output port
- 4. Display activation button

4. Operation

Charging the Power Bank

1. Connect the supplied USB-C cable to the USB-C port.
2. Connect the other end to a power source.
3. The LED display lights up and shows the battery percentage.
4. The green charging indicator lights up during charging.
5. The battery percentage increases during charging.
6. When fully charged, the display shows 100%.

5. LED Display

- Shows the remaining battery percentage.
- The green indicator lights up during charging.
- The percentage increases during charging.
- The button displays the battery level.

Wireless Charging

1. Place your device on the wireless charging surface.
2. Charging starts automatically.
3. The charging icon appears on the LED display.

Compatible with iPhone 12 and later and other Qi-compatible devices (magnetic alignment recommended).

USB-C Charging

1. Connect your device using a USB-C cable.
2. Charging starts automatically.
3. The charging icon appears on the LED display.
4. Supports fast charging up to 20 W.

Checking the Battery Level

Press the activation button to turn on the LED display and show the remaining battery percentage.

6. Safety Information

- Use only with compatible devices.
- Do not expose to liquids or moisture.
- Avoid extreme heat or direct sunlight.
- Do not puncture, crush, or disassemble.
- Do not use if the product is damaged.
- Keep out of reach of children.

7. Safety Features

- Overcharge protection
- Over-discharge protection
- Short-circuit protection
- Overheating protection
- Overcurrent protection

8. Storage and Maintenance

- Store in a cool, dry place.
- Recharge every 3–6 months when not in use.
- Clean with a soft, dry cloth.
- Avoid dropping or exposing to heavy impacts.

9. Compliance

This device complies with Part 15 of the FCC Rules.
Operation is subject to the following conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

10. California Proposition 65 Warning

WARNING: This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

Visit www.reelcharge.com for more information.